

Application / Features Index

This is a partial list of features based on references found in the White Paper Series. Additional features are available in the Custom Application Series

Enhanced Security through Lighting / Automation
for the features listed below more info at
www.x10home.com/pdfdocs/AlrmLite.pdf

- A822 Security Lighting (random lighting while away)
- A823 Alarm Lights (lights on when alarm sounds)
- A824 Smart Timers
- A825 Dusk to Dawn Lighting
- A826 Light the way as you enter a dark house
- A827 Lights on as you enter a room
- A828 Lights off in unoccupied rooms
- B829 Advanced Sensor Controlled Lighting
- B830 Lights Off as Arming Occurs
- A831 Daily Lights Off
- B832 Power Failure Notification
- B881 Setup Insteon Home Automation
- B882 Add second bank (17th) Insteon Serial
- B884 Use Insteon device (e.g. TriggerLinc) as an input

Housekeeper / Guest security
for the features listed below more info at
www.x10home.com/pdfdocs/HousKeep.pdf

- B833 Timed disarm before your guest or housekeeper arrives
- B834 Notification if HouseKeeper/Guest fails to Arm by expected time
- A835 Email Logs at scheduled times
- B836 Log Housekeeper Arrival time
- B837 Log Housekeeper entering forbidden areas
- C838 Automatic Disarm as Housekeeper arrives thru specified door
- C839 Restrict Housekeeper/guest access to portions of property
- B840 Notification when a particular fob is used
- B875 Notification if Housekeeper enters forbidden areas
- A886 Remotely Arm/Disarm by sending Email

Family Safety

for the features listed below more info at
www.x10home.com/pdfdocs/Family.pdf

- B841 Notification if family members fails to arm/disarm by expected time
- B842 Notification when child arrives home from school
- B843 Log child entry into forbidden areas
- D844 Alert if Elder is Inactive
- B845 Indicator Light reminds if Door is Open
- C846 Automatic Disarm as your child arrives home
- B876 Notification if child enters forbidden areas

Buttons

for the features listed below, more info at
www.x10home.com/pdfdocs/Buttons.pdf

- B847 Panic Button
- B848 Button Summons Aid under Duress / Home Invasion
- B849 Button Summons Neighbors
- B850 Button Summons Paramedics
- C851 Button - Investigating suspicious conditions
- C852 Button - Not feeling well; monitor my condition
- B853 Button turns Lights On or Off

Advanced Arming Features

for the features listed below, more info at
www.x10home.com/pdfdocs/ArmFeat.pdf

- B854 Smart Exit Delay - Cell Notification confirms exit
- C884 Daytime Security - Select Doors Beep to Indicate Entry
- B855 Vacation Mode Arming
- C856 Verify Alarms using multiple sensors; multiple trips
- C857 Night Security - Partial Arming
- C858 Night Security - Automatic Disarming as you leave bedroom
- C877 Night Security - Automatic Disarming as you leave bedroom - fob authorized
- B859 Lights On/Off as you leave the bedroom (requires C858)

- B878 Button Operates Lights for nighttime bathroom/kitchen trips
- B879 Automatic Lights for nighttime bathroom/kitchen trips
- C860 Seia Arming Algorithm Enable
- B880 Use NetWatchman as an alarm/wakeup clock
- C885 Alarm Confidence Monitor
- B886 Cell phone confirms arming as you drive away
- B887 Flash exterior lights to confirm arming

Phone Management / CallerID Features
for the features below, more info at
www.x10home.com/pdfdocs/CallerID.pdf

- A861 Log CallerIDs
- A862 Log the names of incoming callers
- A863 Receive email notification when a special caller leaves a message
- A864 Screen Calls; for select calls sound a chime or operate a light
- B865 A call from your cell permits automatic disarm thru a keyed door

Sprinkler System
www.x10home.com/pdfdocs/Sprinkler.pdf

- C866 Sprinkler System setup

Thermostat / Temperature Logging Features
for the features listed below, more info at
www.x10home.com/pdfdocs/Thermal.pdf

- A867 Smart Thermostat (software setup - requires hardware intf)
- A868 Setback Thermostat (software setup - requires hardware intf)
- A869 Display Status on your PC (software setup - requires hardware intf)
- A870 Use Router Module as temperature sensor (software setup for hardware)
- A871 Periodically Log temperature
- A872 Log Daily High/Low Temperature
- B873 Notification of Temperature Limit Exceeded
- B874 Fob selects comfort temperature